



· WHERE WILL YOUR ·
ADVENTURE
TAKE YOU...

· INSTRUCTION MANUAL ·



STAR SHADE CANOPY

(AND CANOPY WALLS)



SCAN HERE
FOR VIDEO
TUTORIALS!

COMPONENTS CHECKLIST

☐

STAR SHADE CANOPY

☐

RUBBER Mallet

☐


FULL SET OF STEEL PEGS

☐

XI CENTRE POLES

☐

INSTRUCTION MANUAL





PLOT PREPARATION + PITCH PERFECTION




ACHIEVING PITCH PERFECTION



- ✓ Ensure your plot is flat and bump free, uneven surfaces or hill tops may apply too much uneven tension and result in damage.
- ✓ Avoid pitching your canopy under trees.
- ✓ Kinks and creases in the fabric suggest that the tension in the tent is uneven and can result in damage. When pitching your canopy, ensure that the centre pole is straight and canopy legs are adjusted accordingly.

ONCE IT'S UP..



- ✓ Frequently check that the pegs are secured tightly and have not become loose, this is particularly important after wet weather as the grounds will become soft.
 - ✓ If you spot any marks, dirt or mildew spots, tackle them right away to prevent the issue from staining or spreading.
- 

WATERPROOFING and LEAK PREVENTION



On the first occasion that your tent experiences a heavy rainfall, although unlikely, you may find small leaks around the seams of the fabric. Do not worry, as this is normal!

Once it has fully dried out, the cotton will naturally shrink and close any holes to ensure your tent becomes completely watertight.

To completely avoid this when on your camping adventure, you can erect the tent in your garden (if possible) and hose it down with water.





IT IS RECOMMENDED
YOU HAVE X2 PEOPLE
PITCHING THE STAR
SHADE CANOPY

TOP TIP!

PITCHING YOUR STAR SHADE CANOPY



1A. UNPACK YOUR STAR SHADE CANOPY
AND ASSEMBLE YOUR CENTRE POLE.

1B. ENSURE THAT THE GROUND YOU'RE
PITCHING ON IS A LEVEL SURFACE,
FREE OF SHARP OBJECTS.

2A. LOCATE THE CONE INSIDE OF THE CANOPY,
THEN PUSH THE POLE UP VERTICALLY UNTIL
STRAIGHT AND CENTRED.



3A. WHILE ONE PERSON SECURES THE CENTER
POLE IN PLACE, THE OTHER SHOULD PULL ONE
OF THE CANOPY LEGS TAUT AND FASTEN THE
CANOPY FOOT TO THE GROUND USING A
PROVIDED REBAR PEG.

3B. REPEAT THIS STEP FOR ALL X6 LEGS.

4A. ONCE ALL CANOPY FEET ARE PEGGED
DOWN, YOU CAN ADJUST THE TENSION OF
THE WEBBING STRAPS. THIS WILL HELP
ENSURE THAT THERE IS EQUAL TENSION
THROUGHOUT THE CANOPY.



**TIP: MAKE SURE TO POSITION THE CANOPY LEGS STRAIGHT WHEN
SECURING THEM, AVOIDING ANY TWISTING OF THE FABRIC, AS THIS CAN
LEAD TO UNEVEN TENSION.**



ATTACHING YOUR CANOPY WALLS

(wall panels are sold separately and individually!)

1A. UNPACK YOUR STAR SHADE CANOPY WALL AND LAY IT FLAT.

2A. MAKE SURE THAT THE CANOPY IS ORIENTED CORRECTLY, WITH THE X3 BUCKLE STRAPS POSITIONED NEAREST TO THE CENTRE POLE.




2A. SECURE THE X3 BUCKLES INTO THE LOOPS LOCATED ABOVE THE CANOPY ARCH.

2B. YOU CAN TIGHTEN THEM INDIVIDUALLY USING THE ADJUSTABLE STRAPS.

3A. LOCATED ALONG THE CANOPY LEGS, YOU WILL FIND LOOPS POSITIONED THROUGHOUT.

3B. ATTACH BOTH SIDES OF THE CANOPY WALLS TO THESE LOOPS USING THE CLIPS FOUND ON THE SIDES OF THE CANOPY WALLS.



4A. YOU WILL THEN NEED TO SECURE THE BOTTOM OF THE CANOPY WALL USING THE X3 REBAR PEGS INCLUDED.

4B. MAKE SURE TO PULL THE FABRIC TAVT, AS SHOWN.

CLEANING YOUR STAR SHADE CANOPY



To remove any dirt, light marks or mud off your canopy you will need to pitch it before cleaning. To tackle marks we advise a soft mop, a soft brush and sponge to apply either:

'NIKWAX TENT AND GEAR SOLARWASH' OR 'NIKWAX COTTON PROOF'

...before rinsing off with water.

To remove any dirt, light marks or mud off your canopy you will need to pitch it before cleaning. If you're looking to wash the whole canopy we advise mixing the cleaning agents above with water in a pump action pressure garden sprayer.

SHOP OUR
CLEANING
PRODUCTS



WATCH
DEMONSTRATION
VIDEO





REPROOFING YOUR STAR SHADE CANOPY

Your canopy will have a generous coating of our water, rot and UV repelling agent. Over time, as a result of heavy use or testing environments, your tent fabric may require a second coating to revive breathability and resistance to the elements.

This can be done by using a garden spray to apply the following agents:

'NIKWAX TENT AND GEAR SOLARWASH' OR 'NIKWAX COTTON PROOF'

READ OUR FULL
MAINTENANCE
GUIDE




RETURNS POLICY

We are certain you are going to love your item/s, however, if you have a change of heart you are entitled to a refund or exchange within 14 days of receiving your item/s. Please note, unpackaged or used items may be subject to this. To make your request, please complete the online returns form on our website:

www.boutiquecamping.com/return-form-i524



LET'S CONNECT!



We'd love to see where your adventure takes you!

Whether it's a reel, a pitching time lapse, or a stunning setup pic, let us and the world see! Don't forget to give us a follow and TAG us, your creation could be featured on our socials and website!

🇬🇧 www.boutiquecamping.com | +44 (0) 203 319 1315 | info@boutiquecamping.com

🇺🇸 www.belltent.com | +1(929) 334 3212 | info@belltent.com